



## WiFi HD Battery Camera Quick Operation manual



IOS APP



Google APP

### I. APP Installation.

#### 1. Android Mobile Phone Download Method;


- 1) Search "Microshare" in the Android mobile software market to download and install the app;
- 2) Computer-side: <http://www.netcam360.com>, and select "Microshare Android Download" to download and install;
- 3) Use your phone to scan the QR code below to install APP.

#### 2. IOS Mobile Phone Download Method;

- 1) Search "Microshare" in the IOS mobile software market to download and install the app;
- 2) Use your phone to scan the QR code below to install APP.

### II. Preparatory Work Before Connection

1. Check the wireless network environment, and ensure that it works under 2.4GHz, (this device does not support 5G) to ensure that your smartphone has been connected to the router;
2. To be able to power up, reset or insert the SD card inside the camera, you must unscrew the back case of the camera with the given screw driver shown below:



Screws.



DC power supply

Power button

Reset Button

SD card slot

3. Powering up the device: Please press the camera "power" key for 8 seconds with the given pin, then release, and you will hear voice prompts "Welcome to use". Make sure that there is red light
4. Resetting the device: Please press the "reset" key with the given pin then release.

### III. The First Time to Connect the Device

After the first use or replacement of the network environment, the Wi-Fi battery camera must follow the following steps to successfully configure Wi-Fi before the camera can be used properly;

Tips: The device don't have led, and when you operate Wi-Fi configuration process, please configure Wi-Fi according to the camera voice;

Step 1. Open the mobile app "Microshare" application, click "Registered Account". When registering your account. Make sure not to include the first zero of your mobile number since the area code is +61. Next, you will need create your password and then you will need the verification code which can be obtained by pressing on "obtain code" and you will be texted the code verification code.

Step 2. After the successful registration, click "Finish", and you may return to the app homepage to login into your account/

Step 3. When logging into your account do not put in the first zero of your number. For example, your login account will be 4XXXXXXXXX.

Step 4. Enter the app main interface and click "+" to add the device.



Step 5, Select “One Key Add Device (sounds)”;


Step 6. Enter the Wi-Fi name and password, press "Connect Wi-Fi";

Step 7. The phone will begin to emits sound waves, as the equipment starts to configure the Wi-Fi;

Step 8. Device sends out the successful configuration voice prompt “Connection has been accepted”, “Connection successful”. You will then be able to click on the “add” key to add device successfully. It may take a while for the device to be connected.

Step 9. Select the equipment placed scene, then press "Sure";

Steps are also shown with the images below:




#### IV. Viewing Videos saved in the SD card.

Before viewing videos in the SD card, you must know how to insert the SD card inside the SD slot of the camera. The image at the right shows how the SD card must be inserted:






Step 1: You must press on the “play” icon to view the video from the camera





Step 2: While the device is recording press on the “choose” key to view the video from the SD card.



- Turn on/off speaker for mobile phone
- Takes photo & saves on mobile phone
- Turn on/off speaker for camera
- Records video & saves on mobile device
- Quality of camera

Step 3: Choose the date, month and year you want to view recorded clip.



Step 4: View the recorded clips from the SD card. The blue lines show video is recorded whereas the grey background means that it was not recorded (video will be recorded when motion is detected only)

Step 5: To be able to view realtime video again, press on the “Realtime” key.




## V. Using Cloud Storage

Step 1: Press on the cloud storage key.

Step 2: You must purchase the cloud storage to be able to use cloud storage. To do that you press on purchase.

Step 3: Then you can choose to have a 30-day free trial before purchasing or you can purchase it straight for \$5/month


Step 4: You now will be able to view the recorded clip via cloud storage.






## VI. Setting up Alarm & Time Zone Settings


Step 1: Press on the settings key



Step 2: Press on alarm setting if you want to change the alarm settings, or press on time zone set to set the time zone.




Step 3: For the alarm settings the 'PIR alarm arm' must be turned on. The time zone settings however you desire, but make sure you click on the "save" key on the top right corner after you're done.




## VII: Setting up the push alert.

The push alert is in the account icon at the bottom right corner and you simply turn on/off the push alert.




## VIII. Sharing device with others.

Step 1: You will need to press on the "share device" key.




Step 2: Then you will require to enter the recipient's account either their mobile number or email. Then press "Sure"

Note: The recipient must also register a "Microshare" account and their mobile number  
Enter mobile number without the "0"  
4XXXXXXXXX.






Step 3: The recipient will receive a notification to whether accepts or refuses sharing the device.



## IX. Adjusting Volume for Mic and Speaker

Setting> Device information>Mic

Setting> Device information>SPK





## X. View video on desktop PC or MAC


Step 1: Install CMS Software for PC via  
<http://d.jooan.cc/>

Step 2: Download CMS Software for PC  
OR


Step 2: Download Apple Client CMS of  
PC for MAC



Step 3: Enter mobile number without the  
“0” 4XXXXXXXX. Enter Password.




Step 4: Refresh My Devices, video can be  
seen by double clicking on the video



## X. Change password for Apps

Step 1: Click on Forgot password, and  
create a new password






## How to connect the device using AP mode

Step 1: Press and hold the reset button for 15 second and release, then you will hear voice prompt "switched to AP"

Step 1: Select onekey add device (AP)



Step 2: Click on Wifi Configuration and follow the prompt

