

What's in the box
Description
Install

QUICK GUIDE

Please consult this checklist for all parts.

Camera	Bracket	USB cable
Bracket	Screws	Manual
Adhesive tape	Tweezer	

Power Port	DC 5V±10%
Power on/off	Press the button for 3 seconds to turn on/off the camera
Status light	<ul style="list-style-type: none"> • Red light solids on: the camera network is abnormal • Red light blinks: awaiting WiFi connection, or currently connecting (faster blinking) • Blue light solids on: camera running correctly
SD card slot	Support local SD Card storage (Max.128G) It is recommended to plug in or remove SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And use the tweezer to remove the SD card from the camera.
Reset	Press and hold on for 5 seconds to reset the camera
Battery capacity	6400mAh (Two 18650 lithium-ion batteries)

1. Fix the bracket on the wall

2. Adhere the machine to the stand
Turn the nut and fix the bracket

Connect
FAQ
Functions
Warning

Download

CloudEdge is available for both iOS and Android OS. Search the name 'CloudEdge' in App Store or Android Market, or scan below QR-Code to download the App.

Download App(iOS&android)

Add device

Log in the CloudEdge, select "Add Device", and add the smart camera to the App according to the screen tips(Make the smart camera close to the router when configuring).

NOTE:if you need to re-select the WiFi network, please press and hold the "RESET" button for 5 seconds, the device will restart, and the indicator will be flashing red.

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.

Q: How to cut the camera network to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why doesn't the device identify the SD card?

A: It is recommended to plug in SD card after power cut. Confirm whether the SD card is normally available and the format is FAT32. And the TF card can't be identified when the internet environment is not good.

Q: Why I can't get the notifications with my cell phone App?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.

Remote wake-up

The camera will be in a sleep mode to save power; you can have a preview in App.

Full-duplex audio

You can see and hear the visitor in your App from the camera.

PIR

When the camera detects someone stopping by, it sends an alarm message to your cell phone.

Low battery alarm

When the battery power is lower than your set, the App will send a notification to your mobile phone.

Record

Using SD card or opening the Cloud-Storage Service, to keep recording for every moment.

Day & Night

Powerful night vision means no interruptions, even in complete darkness.

Warning

1. The camera with built-in battery cannot be put into fire to prevent the battery from exploding;
2. Do not drop the camera on ground and avoid strong impact;
3. Avoid keeping in humid, dusty, extremely hot, extremely cold, strong electromagnetic radiation or other places;
4. Do not put the camera into water;
5. Do not disassemble the product without permission.